



Connect Bricco to the electrical grid through the cable supplied in the packing to pay attention on the feed required from the machine.



We suggest ,for a correct cleaning, to wash the tap and the saucepan in the dishwasher (only for the model "ME"). Disassemble rotating in anti-clockwise direction (saucepan and/or tap) and assemble in a clockwise direction.

Make sure that all components have been well tightened to avoid liquid leak, that could compromise the Bricco's working.






Via del Pantano 16/g - 50013 Campi Bisenzio (Fl) Italy - Tel: +39 055 8986234 - Fax +39 055 8945871 email: Bricco@artesinox.com




Electronic panel

5



.10-04 BK0113WE/10 .02-04 BK0113WL10 .02-04 BK0113WL2 .02-05 BK0113W2





4

Install Bricco, for a correct working, to keep minimum distance indicated on the picture

